





AIR-CELL®

Shed Insulation Installation Instructions


New Shed - Roofs




1. Lay Kingspan AIR-CELL Insulshed® 50 perpendicular to purlins ensuring a 25 mm overlap into the gutter.




2. Allow a nominal 40 mm sag between purlins. If mesh is used, ensure that the mesh is installed loosely to allow for this sag.



3. Overlap by 50 mm at joints and apply 72 mm reinforced foil tape to top of joint. Alternatively allow 150 mm overlap when joints are not to be taped.



4. Use a plastic squeegee or blade to apply appropriate pressure to the tape. End joints should be overlapped by 600 mm if not taped.




5. Fix roof sheeting by screwing through Kingspan AIR-CELL Insulshed 50 to the purlins.

Retrofit - Roofs


1. Roll out Kingspan AIR-CELL Insulshed 50 perpendicular to the purlins.
2. Fix to the purlins using 12 g x 25 mm Tek screws or similar.
3. Use 4 screws across the width of the roll at each purlin, with one 25 mm from each edge and the other two at approx. 430 mm centres.
4. For neatest finish, butt joins rolls and tape joins with 72 mm reinforced aluminium tape. Alternatively, rolls can be overlapped by 50 mm and taped as above.
5. At connections between purlin and frame cut a slot in the Kingspan AIR-CELL Insulshed 50 to allow it to pass over or behind the frame.
6. Neatly cut Kingspan AIR-CELL Insulshed 50 around penetrations and tape if necessary.
7. Reveal skylights by lining beneath, as for roof, and then cut down the centre and diagonally to the corners forming flaps. Curl these flaps back under the roof to reveal the skylight and fix in position by taping or otherwise.

Shed Insulation Installation Instructions


New Shed - Walls



1. Fix Kingspan AIR-CELL Insulshed 50 loosely to the outside of frame leaving flexibility for the insulation to be dished onto the wall cavity.




4. Provide for outer air space by adhering the Kingspan AIR-CELL Spacer Biscuits™ to the outer face of the Kingspan AIR-CELL Insulshed 50 (approximately 3 Spacer Biscuits per square metre required, Spacer Biscuits comes with a peel off self-adhesive backing).



2. Cut Kingspan AIR-CELL Insulshed 50 carefully around doors, windows and other openings, so that it neatly abuts to frames.



5. Commence installing cladding in accordance with manufacturer's installation instructions.



3. Butt join Kingspan AIR-CELL Insulshed 50 sheets and tape with a 72 mm wide reinforced foil tape.

Retrofit - Walls

1. Fix Kingspan AIR-CELL Insulshed 50 to the inside of the frame or girts using 12 g x 25 mm Tek screws or similar, ensuring it is taut.
2. Use 4 screws across the width of the roll at each girt, with one 25 mm from the edge and the other two at approximately 430 mm centres.
3. For neatest finish, butt join rolls, alternatively overlap by 50 mm, and tape joins with 72 mm reinforced aluminium tape.
4. Cut Kingspan AIR-CELL Insulshed 50 carefully around the windows, doors and other openings, so that it neatly abuts to the frame.
5. Penetrations for services should be neatly cut to minimise gaps.

Australia

Kingspan Insulation Pty Ltd

T: 1300 247 235

E: info@kingspaninsulation.com.au

www.kingspaninsulation.com.au



© Kingspan, AIR-CELL, Insulshed and the Lion Device are Registered Trademarks of the Kingspan Group plc in Australia and other countries. All rights reserved. © Kingspan Insulation Pty Ltd.

Kingspan Insulation Pty Ltd reserves the right to amend product specifications without prior notice. The information, technical details and fixing instructions etc. included in this literature are given in good faith and apply to uses described. Recommendations for use should be verified as to the suitability and compliance with actual requirements, specifications and any applicable laws and regulations. For other applications or conditions of use, Kingspan Insulation offers a Technical Advisory Service the advice of which should be sought for uses of Kingspan Insulation products that are not specifically described herein. Please check that your copy of the literature is current by contacting us or visiting <https://www.kingspan.com/au/en/products/insulation/roof-insulation/air-cell-insulshed-50/>

